

## **TECHNICAL NOTE**

This technical note deals with the use of a Biaxial Geogrid layer above Eco-Rain Tank structures.

Eco-Rain Tank Systems recommends the use of Biaxial Geogrid 12 inches below sub-grade in vehicular traffic applications.

This recommendation is based on increasing the safety factor due to possible lack of compaction during backfill - the Geogrid will create a "bridge" in weak soil areas.

Overlap the Geogrid at least 3 feet beyond the perimeter of the Eco-Rain Tank structure. Place 2 inches of gravel under and over the Geogrid - this will secure the Geogrid in place with the required tension for proper functioning. Pin the Geogrid to the undisturbed side walls.

Alternately, a layer of Eco-Rain 2" Drainage Cells wrapped in non-woven Geotextile material can be used instead of the Biaxial Geogrid to provide more strength and disbursement of load. A layer of Eco-Rain 2" Drainage Cells withstands 405 psi loading. Install as above.

While Eco-Rain Tank Systems recommends the use of Biaxial Geogrid or Eco-Rain 2" Drainage Cells in vehicular traffic applications like parking lots, it is the Engineer's decision to specify its use. Installers must follow the Engineer's specification.

DISCLAIMER: All information provided in this publication is correct to the best of the Company's knowledge and is given out in Good Faith. This information is intended only as a general guide, no responsibility can be accepted for any errors, omissions or incorrect assumption. As each project is unique, and as Eco-Rain Tank Systems and Its distributors and agents worldwide have no direct control over the methods employed by the user in specifying, installing or supervising its products. No responsibility is accepted by Eco-Rain Tank Systems and/or its distributors and agents worldwide. Users should satisfy themselves as to the suitability of the product for their purpose.